

## Please attach the strips with residue-free textile adhesive tape as follows:



If required, additional fastening can be applied along the center line. In practice, 1 m (3.3 ft) of tape per side is usually sufficient.

Fix one end of the piste first and unroll it for approximately 10 m (33 ft). Then pull the piste gently taut and secure the opposite end, ensuring the surface remains smooth and free of waves.

Only use appropriate fencing shoes on the piste. Protect the piste from dirt and rubber abrasion.

After each use, remove any dirt (e.g., by sweeping or vacuuming).